

# KUKA



## ready2\_educate Level 1

Target Group: School and College Students



Issued: 29.11.2017

Version: ready2\_educate - Level 1 V1



© Copyright 2017

KUKA Roboter GmbH  
Zugspitzstraße 140  
D-86165 Augsburg  
Germany

This documentation or excerpts therefrom may not be reproduced or disclosed to third parties without the express permission of KUKA Roboter GmbH.

Other functions not described in this documentation may be operable in the controller. The user has no claims to these functions, however, in the case of a replacement or service work.

We have checked the content of this documentation for conformity with the hardware and software described. Nevertheless, discrepancies cannot be precluded, for which reason we are not able to guarantee total conformity. The information in this documentation is checked on a regular basis, however, and necessary corrections will be incorporated in the subsequent edition.

Subject to technical alterations without an effect on the function.

KIM-PS5-DOC

Translation of the original documentation

Publication: Pub COLLEGE ready2\_educate Level 1 (PDF-COL) en  
Book structure: ready2\_educate - Level 1 V1.37  
Version: ready2\_educate - Level 1 V1

## Contents

<b>1</b>	<b>Course structure</b> .....	7
<b>2</b>	<b>Training module: Introduction to robotics</b> .....	9
2.1	Overview .....	9
2.2	Introduction .....	9
2.3	KUKA company history .....	10
2.4	Applications for industrial robots .....	16
2.5	Examples of robotic applications .....	18
2.6	Learning objective check .....	28
<b>3</b>	<b>Training module: Structure and function of a KUKA robot system</b> .....	31
3.1	Overview .....	31
3.2	Robot basics .....	31
3.3	Robot arm of a KUKA robot .....	32
3.4	(V)KR C4 robot controller .....	34
3.5	Learning objective check .....	37
<b>4</b>	<b>Training module: Robot operation and cell safety</b> .....	39
4.1	Overview .....	39
4.2	The KUKA smartPAD .....	39
4.3	Overview of smartPAD .....	40
4.4	Robot programming .....	41
4.5	Robot safety .....	43
4.6	Learning objective check .....	47
<b>5</b>	<b>Training module: Working with the Navigator</b> .....	49
5.1	Overview .....	49
5.2	Creating program modules .....	49
5.3	Editing program modules .....	52
5.4	Archiving and restoring robot programs .....	55
5.5	Selecting and starting robot programs .....	56
5.6	Performing an initialization run .....	62
5.7	Reading and interpreting robot controller messages .....	63
5.8	Selecting and setting the operating mode .....	65
5.9	Learning objective check .....	67
<b>6</b>	<b>Practical module: Operating the smartPAD and Navigator</b> .....	69
6.1	Safety instruction .....	69
6.2	Exercise: smartPAD and Navigator .....	74
<b>7</b>	<b>Training module: Moving the robot</b> .....	77
7.1	Overview .....	77
7.2	Moving individual robot axes .....	77
7.3	Coordinate systems in conjunction with robots .....	80
7.4	Moving the robot in the world coordinate system .....	82
7.5	Learning objective check .....	87
<b>8</b>	<b>Practical module: Moving the robot manually</b> .....	89
8.1	Exercise: Moving the robot manually .....	90

<b>9</b>	<b>Training module: Mastering the robot and calculating load data</b> .....	93
9.1	Overview .....	93
9.2	Mastering principle .....	93
9.3	Loads on the robot .....	97
9.4	Tool load data .....	97
9.5	Learning objective check .....	100
<b>10</b>	<b>Training module: Working with the tool and base coordinate systems</b> .	103
10.1	Overview .....	103
10.2	Moving the robot in the tool coordinate system .....	103
10.3	Tool calibration .....	107
10.4	Moving the robot in the base coordinate system .....	114
10.5	Base calibration .....	117
10.6	Polling the current robot position .....	123
10.7	Jogging with a fixed tool .....	126
10.8	Learning objective check .....	127
<b>11</b>	<b>Practical module: Moving the robot in the tool coordinate system</b> .....	129
11.1	Exercise: Moving the robot in the tool coordinate system .....	130
<b>12</b>	<b>Practical module: Moving the robot in the base coordinate system</b> .....	133
12.1	Exercise: Moving the robot in the base coordinate system .....	134
<b>13</b>	<b>Training module: Creating point-to-point motions</b> .....	137
13.1	Overview .....	137
13.2	Creating new motion commands .....	137
13.3	Creating cycle-time optimized motion (axis motion) .....	138
13.4	Modifying motion commands .....	144
13.5	Learning objective check .....	147
<b>14</b>	<b>Practical module: Creating a dummy program</b> .....	149
14.1	Exercise: Creating a dummy program .....	150
<b>15</b>	<b>Training module: Creating CP motions</b> .....	153
15.1	Overview .....	153
15.2	Creating CP motions .....	153
15.3	Learning objective check .....	165
<b>16</b>	<b>Practical module: Creating CP motions</b> .....	167
16.1	Exercise: Creating CP motions .....	168
<b>17</b>	<b>Training module: Creating logic functions</b> .....	171
17.1	Overview .....	171
17.2	Introduction to logic programming .....	171
17.3	Programming wait functions .....	172
17.4	Programming simple switching functions .....	176
17.5	Learning objective check .....	179
<b>18</b>	<b>Training module: Programming triggers and gripper operation</b> .....	181
18.1	Overview .....	181
18.2	Programming the spline trigger .....	181

18.3	Gripper operation with KUKA.GripperTech .....	183
18.4	Programming a gripper by means of inline forms .....	184
18.5	Checking a gripper by means of an inline form .....	188
18.6	Learning objective check .....	190
<b>19</b>	<b>Practical module: Logic and switching functions .....</b>	<b>191</b>
19.1	Exercise: Logic and switching functions .....	192
<b>20</b>	<b>Practical module: Component handling exercise .....</b>	<b>193</b>
20.1	Exercise: Part handling .....	194
<b>21</b>	<b>Training module: Working with spline blocks .....</b>	<b>197</b>
21.1	Overview .....	197
21.2	Working with SPLINE blocks .....	197
21.3	Programming spline blocks with inline forms .....	199
21.4	Velocity profile for spline motions .....	200
21.5	Modifications to spline blocks .....	203
21.6	Programming CP SPLINE blocks via inline forms .....	206
21.7	Programming PTP SPLINE blocks via inline form .....	209
21.8	Learning objective check .....	211
<b>22</b>	<b>Practical module: Programming spline blocks .....</b>	<b>213</b>
22.1	Exercise: Programming spline blocks .....	214
<b>23</b>	<b>Training module: Expert programming outlook .....</b>	<b>217</b>
23.1	Overview .....	217
23.2	Working at Expert level .....	217
23.3	Programming an endless loop .....	219
23.4	Linking robot programs with a subprogram call .....	220
23.5	Learning objective check .....	222
<b>24</b>	<b>Practical module: Expert programming .....</b>	<b>225</b>
24.1	Exercise: Expert programming .....	226
<b>25</b>	<b>Training module: Recapitulation and summary, Level 1, Part 1 .....</b>	<b>229</b>
25.1	Overview .....	229
25.2	Recapitulation .....	229
<b>26</b>	<b>Training module: Recapitulation and summary, Level 1, Part 2 .....</b>	<b>237</b>
26.1	Overview .....	237
26.2	Recapitulation .....	237
<b>27</b>	<b>Appendix .....</b>	<b>243</b>
27.1	Working with WorkVisual .....	243
27.1.1	Overview .....	243
27.1.2	Managing a project with WorkVisual .....	243
27.1.2.1	Connecting a WorkVisual PC to the controller .....	244
27.1.2.2	Overview of the WorkVisual user interface .....	244
27.1.2.3	Loading an existing project in WorkVisual .....	246
27.1.2.4	Save WorkVisual project locally .....	248
27.1.2.5	WorkVisual modes .....	249

27.1.2.6	WorkVisual project structure (“Files” tab) .....	249
27.1.2.7	Comparing projects with WorkVisual .....	250
27.1.2.8	Transferring the project to the robot controller (installing) .....	254
27.1.2.9	Assigning the project to the real robot controller .....	265
27.1.2.10	Activating a project on the robot controller .....	269
27.1.3	Editing KRL programs with WorkVisual .....	272
27.1.3.1	File handling .....	272
27.1.3.2	Activating the Templates catalog .....	277
27.1.3.3	Working with the KRL Editor .....	278
	<b>Index</b> .....	<b>291</b>

## 3 Training module: Structure and function of a KUKA robot system

### 3.1 Overview

The following contents are explained in this training module:

- Robot basics
- Robot arm
- Robot controller

### 3.2 Robot basics

#### What is a robot?

- The term *robot* comes from the Slavic word *robota*, meaning *hard work*.
- According to the official definition of an industrial robot: “A robot is a freely programmable, program-controlled handling device”.
- The robot system thus also includes the controller and the operator control device, together with the connecting cables and software.



Fig. 3-1: Industrial robot

- 1 Controller ((V)KR C4 control cabinet)
- 2 Manipulator (robot arm)
- 3 Teach pendant (KUKA smartPAD)

Everything outside the system limits of the industrial robot is referred to as the *periphery*:

- Tooling (end effector/tool)
- Safeguard
- Conveyor belts

- Sensors
- Machines
- etc.

### 3.3 Robot arm of a KUKA robot

#### What is a manipulator?

- The manipulator is the actual robot arm.
- It consists of a number of moving rigid links that are linked together by means of axes.
- The individual axes are moved by means of targeted actuation of servomotors.
- These are linked to the individual components of the manipulator via reduction gears.




Fig. 3-2: Manipulator

- 1 Manipulator (robot arm)
- 2 Start of the kinematic chain: base of the robot (ROBROOT)
- 3 Free end of the kinematic chain: flange (FLANGE)
- A1...A6 Robot axes 1 to 6

#### Overview of manipulator components

- The components of a robot arm consist primarily of cast aluminum and steel.
- In isolated cases, carbon-fiber components are also used.
- The individual components are numbered from bottom (robot base) to top (robot flange):



Fig. 3-3: Overview of manipulator components

1	Base frame	4	Link arm
2	Rotating column	5	Arm
3	Counterbalancing system	6	Wrist

#### Axes of the robot




Fig. 3-4: Axes of a KUKA robot

Excerpt from the technical data of manipulators from the KUKA product range:

- **Number of axes:**
  - 4 axes for KR 40 PA
  - 6 axes for standard vertical jointed-arm robots

- 7 axes for lightweight robots
- **Reach:** from 0.54 m (KR 3 R540) to 3.9 m (KR 120 R3900 ultra K)
- **Weight:** from 23 kg (LBR iiwa 7 R800) to 4700 kg (KR 1000 Titan).
- **Accuracy:** 0.03 mm to 0.2 mm repeatability.



- The axis ranges of main axes A1 to A3 and wrist axis A5 of the robot are limited by means of mechanical end stops with a buffer.
- Additional mechanical end stops can be installed on the external axes.

#### NOTICE

- If the robot or an external axis hits an obstruction or a buffer on the mechanical end stop or axis range limitation, this can result in material damage to the robot system.
- KUKA Roboter GmbH must be consulted before the robot system is put back into operation.  
The affected buffer must be replaced with a new one before robot operation is resumed.
- If the robot (or external axis) collides with a buffer at more than 250 mm/s, the robot (or external axis) must be exchanged or recommissioning must be carried out by KUKA Roboter GmbH.

### 3.4 (V)KR C4 robot controller

**Who controls motion?**

The manipulator is moved by means of servomotors controlled by the (V)KR C4 controller.



Fig. 3-5: (V)KR C4 control cabinet

#### Properties of the (V)KR C4 controller

- **(V)KR C4 controller**  
 Robot controller (path planning): control of six robot axes plus up to three external axes.




Fig. 3-6: (V)KR C4 axis control

- **(V)KR C4 extended controller**  
 Robot controller (path planning): control of six robot axes plus up to six external axes.



Fig. 3-7: (V)KR C4 extended axis control

### ■ Software-based controller



**Fig. 3-8: Block model**

- KR C4-based controllers work on a modular control concept.
- The **KPC-KUKA PC** plays a central role here.
- Robot programs access the required hardware interfaces via task-specific applications.
- In addition to **system-relevant applications** that are always available, the controller can also have **customer-specific applications** added to it.

The **system-relevant applications** include:

- **RC (Robot Control)**  
KUKA kernel system of the robot controller
- **Safety**  
Integrated KUKA safety controller

The **customer-specific options** include (selection):

- **PLC**  
Soft PLC (KUKA.PLC in accordance with IEC61131) that can be integrated for general sequence control
- **XM (eXtendedMotion)**  
Runtime system that can be integrated for a KUKA MotionControl library
- **Process control**  
General platform for integration of process controllers  
e.g. integration of vision capability

## Communication options



Fig. 3-9: (V)KR C4 communication options

- Communication options via bus systems (e.g. ProfiNet, Ethernet IP, Interbus)
  - Programmable logic controllers (PLC)
  - Additional controllers
  - Sensors and actuators
- Communication options via network
  - Host computer
  - Additional controllers
  - Service notebook

### 3.5 Learning objective check

#### Revision questions

After this training module, these questions should no longer be a problem for you:

What are the components of a KUKA robot system?

.....  
 .....

What is meant by peripheral equipment in this context?

.....  
 .....

What distinctive points on the robot kinematic system are you familiar with?

.....  
 .....

What system size can a standard KR C4 robot controller manage?

.....  
 .....

## 6 Practical module: Operating the smartPAD and Navigator

### 6.1 Safety instruction

#### Hazards when working with a KUKA robot system

There are always certain residual risks from a robot system. Correct operator control and observation of the safety-relevant aspects is thus essential for safe operation.

Mechanical hazards:

- A KUKA robot is **always stronger than you**.
- The path of a robot is **not foreseeable in all cases**.

Electrical hazards:

- A robot is an electrical machine with **hazardous voltages and currents**.

#### Safety when working at the mobile training cell

A number of fundamental rules apply when working in the practical modules:

- The instructions issued by the course instructor must be observed.
- Do not perform any actions that you are uncertain about. If in doubt, ask the course instructor.
- The course instructor determines the maximum motion velocity of the robot. This velocity must not be exceeded under any circumstances.
- If in doubt, always press the EMERGENCY STOP button on the smartPAD or on the cell immediately. This safety facility is not merely there for decoration, but to be used. It is better to press the EMERGENCY STOP button too often rather than not often enough.
- The EMERGENCY STOP button is locked in place when the training cell is left.
- The person holding the smartPAD is responsible for the robot cell and for their colleagues. Do not act recklessly or in a way that could result in injuries to other participants in your group or damage to the robot system. In return, the other participants in your group are under the obligation to follow your instructions.
- If the robot is moved, the eyes and concentration of all persons at this cell must be focused on the robot. Furthermore, no extraneous activities are allowed during this time. The current motion velocity has no bearing on this.
- Every program must be tested after any modification. The path of the robot is dependent, among other factors, on the velocity that has been set! It is thus not possible to assume that the robot will behave in the same way at T1 100% as at T2 75%, for example. Testing must therefore be carried out step by step: Always increase the velocity one step at a time until the value specified by the course instructor has been reached. Only then may you switch to automatic mode (once again with the value specified by the course instructor and not simply 100%) and allow the program to run automatically. This procedure must be followed even if only a small modification has been made to the program, as the robot motion cannot always be predicted.

**Safety when  
working with the  
KUKA  
ready2\_educate  
training cell**

**⚠ DANGER**

- In the absence of functional safety equipment and safeguards, the robot system can cause personal injury or material damage.
- If safety equipment or safeguards are dismantled or deactivated, the robot system may not be operated.


The KUKA ready2\_educate training cell has a pneumatic gripper. This can exert a force that is hazardous to humans. In some practical modules, you will have to load a component into the gripper by hand.



**Fig. 6-1: Clamping components**

**⚠ DANGER**

- When using the gripper system there is a risk of crushing and cutting.
- Great care must therefore be taken when clamping manually.



**Fig. 6-2: Gripper keys**

- The gripper can be opened and closed in T1 mode using the two status keys at the bottom left-hand side of the smartPAD.
- The enabling switch must be pressed for this.

### What to do in case of an accident

In the event of an accident, the following procedure should generally be followed:



1. Secure the accident site
2. Fetch help
3. Rescue injured persons and provide first aid

What this specifically means in the case of an accident at the training cell is:

#### ■ Secure the accident site

Stop the robot (EMERGENCY STOP, switch off the power supply to the laboratory, pull out the plug, etc.) and depressurize pneumatic components if applicable (disconnect compressed air supply). In the case of accidents with electric current, switch off the power supply. Do not enter the danger area yourself, however. Your own safety has top priority. It does not help anybody if you get yourself knocked down, for example, while trying to rescue an unconscious person from an area in which a machine is still active.

#### ■ Fetch help

Notify the responsible first aider (generally the course instructor) and the emergency services. Also warn other people who could still be endangered.

#### ■ Rescue injured persons and provide first aid

If the injured person has been trapped by the robot, release him from this situation by using the available method for moving the manipulator without the robot controller. Do not reactivate the robot controller under any circumstances! Perform first aid until the responsible first aider or emergency services arrive.

### Options for moving the manipulator without the robot controller

The following options are available for moving the manipulator after an accident or malfunction:

#### ■ Release device (optional)

The release device can be used for the main axis drive motors and, depending on the robot variant, also for the wrist axis drive motors.




**Fig. 6-3: Release device**

#### ■ Brake release device (option)

The brake release device is designed for robot variants whose motors are not freely accessible.

Example for AGILUS:



**Fig. 6-4: Hand-held device**

- 1 Hand-held device
- 2 Pushbutton S1

■ Moving the wrist axes directly by hand

There is no release device available for the wrist axes of variants in the low payload category. This is not necessary because the wrist axes can be moved directly by hand.

The options are only for use in exceptional circumstances and emergencies, e.g. for freeing people.

**i** Information about the options available for the various robot models and about how to use them can be found in the assembly and operating instructions for the robot or requested from KUKA Roboter GmbH.

**⚠ CAUTION** The motors reach temperatures during operation which can cause burns to the skin. Contact must be avoided. Appropriate safety precautions must be taken, e.g. protective gloves must be worn.

**i** The KUKA ready2\_educate training cell comes equipped with either the KR 3 R540 or the KR 6 R700. The brake release device option is available for these robot types. If you have a different robot type, please contact the department responsible for information about the options for moving the robot axes.

**Safety questions**

Before commencing the practical exercises, you must first answer these safety questions and receive clearance from the course instructor to start the practical module.

What is the maximum velocity at which the robots are allowed to move?

.....  
 .....

What action do you take if the robot moves unpredictably and there is a risk of a collision?

.....  
 .....  
 .....

You have the smartPAD in your hand and want to test a program in T1 mode with the safety gates open. You notice that your colleague is leaning against the cell with his back to the robot and staring at his cellphone. What do you do?

.....  
.....  
.....  
.....  
.....

You notice damage or a modification to the training cell that could have a detrimental effect on the safety equipment. What do you do?

.....  
.....  
.....  
.....  
.....

How can you move the robot without a controller?

.....  
.....

What do you do in the event of an accident?

.....  
.....  
.....  
.....

## 6.2 Exercise: smartPAD and Navigator

### Aim of the exercise

On successful completion of this exercise, you will be able to carry out the following activities:

- Operating the smartPAD
- Working correctly with the Navigator
- Working in projects, archiving programs
- Selecting programs, performing a BCO run and starting programs

### Precondition

- Training module: Working with the Navigator
- Safety instruction with answering of safety questions

### Safety instructions

You must test every program before operation. The procedure for a program test is always the same.

#### ■ T1

Test your program in T1 mode, increasing the velocity up to 100%.

#### ■ T2

Test your program in T2 mode, gradually increasing the velocity up to the maximum velocity specified by the course instructor (% or m/s). Always increase the velocity in small steps only, as the path may vary depending on the velocity.

#### ■ AUT

Now you can use your program in AUT mode up to the maximum tested velocity.



- If a program is not tested thoroughly enough, or not tested at all, this can result in injury to persons and damage to property!



Ensure that the correct Tool and Base settings are used. If the tool is modified, components on the application plate are shifted or a new form is loaded into the clamping fixture, Tool and Base must be recalibrated.

### Working in the practical modules

In the following exercises, you will always be working on a project of your own. At the start of the subsequent practical module, please always check whether the correct project is selected. You will not be reminded of this in the following practical modules. If a different project has been activated in the meantime, the course instructor will help you to change back to your project.




Fig. 6-5: Active project

If you have created contents using KUKA.OfficeLite, the simplest way of transferring them to the robot controller is to use a KUKA USB stick.

### Task description

1. Together with the course instructor, create a copy of the base project and rename it with your name.
2. Ensure that operating mode T1 is set.
3. Navigate to the Programs folder and select the program module *Demo()*.

4. Test the program. Caution: During the first program test, or if the program is restarted during the motion, the robot performs a BCO run.
5. Run the program in automatic mode.
6. Deselect the program again.
7. Create an archive of your project on the KUKA USB stick with the setting "All".